



06701-9383-0  
info@ibs-scherer.de

## Overview

# IBS ultrasound device USI-210

Product number: 2320004





## Description

### Description

The IBS ultrasonic cleaning device USI-210 is very easy to use. The parts to be cleaned are simply placed in the basket and the cleaning concentrate is added to the bath liquid. For ultrasonic cleaning, we recommend our IBS special cleaner WAS 10.500 (for oil and grease soiling) or our WAS 20.100 (for combustion residues, coking, pigments). The appliance is then switched on and the cleaning process starts. The cleaning time depends on the degree of soiling of the parts. As a rule, however, it only takes a few minutes.

The IBS USI-210 ultrasonic cleaning device is suitable for cleaning a wide variety of tools and components. These include, for example

- Screws, nuts, fasteners
- tools
- Small parts such as electronic parts and components

The advantages of the IBS USI-210 ultrasonic cleaning device at a glance:

- Thorough and gentle intensive cleaning of tools and components of different geometries, types and sizes
- Robust stainless steel construction
- Basket and lid included in the scope of delivery
- Simple operation
- Easy cleaning and care of the appliance

## Product information

<b>Bath contents:</b>	270 l
<b>External dimensions WxDxH:</b>	930x750x800 mm
<b>Load capacity:</b>	40 kg
<b>Ultrasonic power:</b>	2 x 4000 W